


## Repossi belt rakes – 1 belt

### Assembling instructions

#### 1 – Rake after opening its crate





## 2 – How to assemble the working springs






**Repossi**<sup>TM</sup>  
macchine agricole

**Repossi macchine agricole S.r.l.**

Via V. Emanuele II, 40 - 27022 Casorate Primo (PV) - Italia  
Tel. +39 02 905 66 25 - Fax +39 02 905 13 08  
e-mail: [info@repossi.it](mailto:info@repossi.it) - Web: [www.repossi.it](http://www.repossi.it)

REA 236205

C.F. e P.IVA 01981040189



### IMPORTANT

Keep the spring in tension (up direction) meanwhile you are screwing the bolt (upper picture)







**Repossi**<sup>TM</sup>  
macchine agricole



**Repossi macchine agricole S.r.l.**

Via V. Emanuele II, 40 - 27022 Casorate Primo (PV) - Italia  
Tel. +39 02 905 66 25 - Fax +39 02 905 13 08  
e-mail: info@repossi.it - Web: www.repossi.it

REA 236205

C.F. e P.IVA 01981040189

### 3 – Steering unit (with steering wheels only)






**Repossi**<sup>TM</sup>  
macchine agricole

**Repossi macchine agricole S.r.l.**

Via V. Emanuele II, 40 - 27022 Casorate Primo (PV) - Italia  
Tel. +39 02 905 66 25 - Fax +39 02 905 13 08  
e-mail: info@repossi.it - Web: www.repossi.it

REA 236205

C.F. e P.IVA 01981040189





**Repossi**<sup>TM</sup>  
macchine agricole

**Repossi macchine agricole S.r.l.**

Via V. Emanuele II, 40 - 27022 Casorate Primo (PV) - Italia  
Tel. +39 02 905 66 25 - Fax +39 02 905 13 08  
e-mail: info@repossi.it - Web: www.repossi.it

REA 236205

C.F. e P.IVA 01981040189

#### 4 - Wheels



#### 5 - Side springs

